



ASSEMBLY

NOTES:

1. ONE HOLE NOT CENTERED TO ALLOW NUT TO CLEAR OTHER CARRIAGE BOLT
2. USED TO BOLT 80/20 TO FLOOR
3. ELASTIC STOP NUT USED DUE TO VEHICLE VIBRATIONS
4. LOCATE SS ELEVATOR BOLT HEAD IS BETWEEN CORRUGATIONS OVER CLOSED CELL INSULATION
5. INSTALL ANGLE AND MARK HOLE LOCATION
6. REMOVE PLYWOOD AND DRILL THE 11/32" HOLES
7. USE CONSTRUCTION ADHESIVE UNDER BOLT HEAD AND TIGHTEN WITH A NUT FENDER WASHER TO HOLD

<i>ORTON DESIGN</i>	CONNECTOR "C" - FLOOR 90 DEGREE ANGLE	HALF
	MATERIAL - 3/16 x 1 1/2" ALUMINUM ANGLE	

ODJ127-41